
## Steadfast R IN ASSOCIATION WITH THORHELICAL

# **Brick Beam Lintel Repair System**



#### **METHOD STATEMENTS & NOTES**

- 1. Remove section of mortar to full height in two separate bed joints. Flush with clean water and bond a pair of 6mm Twistfix helical bars, 10mm apart, using WHO-60 grout. Make good joint to match existing.
- Depth of the slots should be 40mm on a half brick single leaf and 55mm on a full brick solid leaf. Treat thicker walls from both sides.
- Ratio between span of opening and distance between top and bottom reinforcement should not exceed 7:1

#### **REINFORCEMENT SPECIFICATION**

• Material:

- 304 Series Stainless Steel
- Ult. Tensile Strength:
- 1050-1200N/mm<sup>2</sup>

55N/mm<sup>2</sup>

 $5N/mm^2$ 

 $12N/mm^2$ 

13N/mm<sup>2</sup>

- Nominal CSA:

- 6mm Bar = 7.4mm<sup>2</sup>

### **GROUT SPECIFICATION AT 28 DAYS**

- Compressive Strength:
- Tensile Strength:
- Flexural Strength:
- Youngs Modulus:

Engineers, surveyors and contractors should refer to BRE Good Building Guide 62 and the BRE Load Tables for retrofit masonry beams formed by Twistfix helical bars set in WHO-60 grout.

ST-LR-SK02